

DynoTune Pressure Gauges

Use this chart for datalogging of all DynoTune Pressure Gauges

Attach your Input to the data logger to the Black pressure Gauge wire

Boost/Fuel pressure Sender Output = .005V per 10 psi

<u>PSI</u>	<u>Vout</u>
0	2.547
10	2.552
20	2.557
30	2.562
40	2.567
50	2.572
60	2.577
70	2.582
80	2.587
90	2.592
100	2.597
110	2.602
120	2.607
130	2.612
140	2.617
150	2.622

Nitrous pressure Sender Output = .005V per 100 psi

<u>PSI</u>	<u>Vout</u>
0	2.547
100	2.552
200	2.557
300	2.562
400	2.567
500	2.572
600	2.577
700	2.582
800	2.587
900	2.592
1000	2.597
1100	2.602
1200	2.607
1300	2.612
1400	2.617
1500	2.622